



## How to Measure Cover Radius

### Cover Radius Calculation Chart

Actual Measurement (centimetres)				Radius to Order (centimetres)
Lower Size	between	Upper Size		
3	and	6	➡	2.5
6	and	10	➡	5
10	and	14	➡	7.5
14	and	18	➡	10
18	and	22	➡	12.5
22	and	26	➡	15
26	and	29	➡	17.5
29	and	33	➡	20
33	and	37	➡	22.5
37	and	41	➡	25
41	and	45	➡	27.5
45	and	49	➡	30
49	and	53	➡	32.5
53	and	57	➡	35
57	and	61	➡	37.5
61	and	65	➡	40
65	and	69	➡	42.5
69	and	73	➡	45
73	and	77	➡	47.5
77	and	80	➡	50

#### EXAMPLE:

Take a measurement between the start and end points of the radius.



My tape reading is 30cm

From Chart my reading is between 29cm and 33cm

29	and	33	➡	<b>20</b>
----	-----	----	---	-----------

**I therefore need to order 20cm radius**